

|            |              |                                                                                |
|------------|--------------|--------------------------------------------------------------------------------|
| <b>DTC</b> | <b>P0450</b> | <b>Evaporative Emission Control System Pressure Sensor / Switch</b>            |
| <b>DTC</b> | <b>P0451</b> | <b>Evaporative Emission Control System Pressure Sensor Range / Performance</b> |
| <b>DTC</b> | <b>P0452</b> | <b>Evaporative Emission Control System Pressure Sensor / Switch Low Input</b>  |
| <b>DTC</b> | <b>P0453</b> | <b>Evaporative Emission Control System Pressure Sensor / Switch High Input</b> |

**ES****DTC SUMMARY**

| <b>DTCs</b> | <b>Monitoring Items</b>                      | <b>Malfunction Detection Conditions</b>                                                                 | <b>Trouble Areas</b>                                                                                                           | <b>Detection Timings</b>                                                                                 | <b>Detection Logic</b> |
|-------------|----------------------------------------------|---------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|------------------------|
| P0450       | Pressure sensor abnormal voltage fluctuation | Sensor output voltage rapidly fluctuates beyond upper and lower malfunction thresholds for 0.5 seconds. | <ul style="list-style-type: none"> <li>Pump module</li> <li>ECM</li> </ul>                                                     | <ul style="list-style-type: none"> <li>EVAP monitoring (ignition OFF)</li> <li>Ignition ON</li> </ul>    | 1 trip                 |
| P0451       | Pressure sensor noising                      | Sensor output voltage fluctuates frequently in certain time period.                                     | <ul style="list-style-type: none"> <li>Pump module</li> <li>Connector/wire harness (Pump module - ECM)</li> <li>ECM</li> </ul> | <ul style="list-style-type: none"> <li>EVAP monitoring (ignition OFF)</li> <li>Engine running</li> </ul> | 2 trip                 |
| P0451       | Pressure sensor stuck                        | Sensor output voltage does vary in certain time period.                                                 | <ul style="list-style-type: none"> <li>Pump module</li> <li>Connector/wire harness (Pump module - ECM)</li> <li>ECM</li> </ul> | EVAP monitoring (ignition OFF)                                                                           | 2 trip                 |
| P0452       | Pressure sensor voltage low                  | Sensor output voltage is less than 0.45 V for 0.5 seconds.                                              | <ul style="list-style-type: none"> <li>Pump module</li> <li>Connector/wire harness (Pump module - ECM)</li> <li>ECM</li> </ul> | <ul style="list-style-type: none"> <li>Ignition ON</li> <li>EVAP monitoring (ignition OFF)</li> </ul>    | 1 trip                 |
| P0453       | Pressure sensor voltage high                 | Sensor output voltage is more than 4.9 V for 0.5 seconds.                                               | <ul style="list-style-type: none"> <li>Pump module</li> <li>Connector/wire harness (Pump module - ECM)</li> <li>ECM</li> </ul> | <ul style="list-style-type: none"> <li>Ignition ON</li> <li>EVAP monitoring (ignition OFF)</li> </ul>    | 1 trip                 |


**HINT:**

The pressure sensor is built into the pump module.

**DESCRIPTION**

The circuit description can be found in the EVAP (Evaporative Emission) System (See page [ES-346](#)).

## MONITOR DESCRIPTION



1. DTC P0450: Pressure sensor abnormal voltage fluctuation  
If the pressure sensor voltage output rapidly fluctuates between less than 0.45 V and more than 4.9 V, the ECM interprets this as an open or short circuit malfunction in the pressure sensor or its circuit, and stops the EVAP (Evaporative Emission) system monitor. The ECM then illuminates the MIL and sets the DTC (1 trip detection logic).
2. DTC P0451: Pressure sensor noising or stuck  
If the pressure sensor voltage output fluctuates rapidly for 10 seconds, the ECM stops the EVAP system monitor. The ECM interprets this as noise from the pressure sensor, and stops the EVAP system monitor. The ECM then illuminates the MIL and sets the DTC.  
Alternatively, if the sensor voltage output does not change for 10 seconds, the ECM interprets this as the sensor being stuck, and stops the monitor. The ECM then illuminates the MIL and sets the DTC.  
(Both the malfunctions are detected by 2 trip detection logic)
3. DTC P0452: Pressure sensor voltage low  
If the pressure sensor voltage output is below 0.45 V, the ECM interprets this as an open or short circuit malfunction in the pressure sensor or its circuit, and stops the EVAP system monitor. The ECM then illuminates the MIL and sets the DTC (1 trip detection logic).
4. DTC P0453: Pressure sensor voltage high  
If the pressure sensor voltage output is 4.9 V or more, the ECM interprets this as an open or short circuit malfunction in the pressure sensor or its circuit, and stops the EVAP system monitor. The ECM then illuminates the MIL and sets the DTC (1 trip detection logic).

## MONITOR STRATEGY

|                               |                                                                                                                                                                                                                                                                                                                 |
|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Related DTCs                  | P0450: Evaporative emission control system pressure sensor/switch chattering<br>P0451: Evaporative emission control system pressure sensor noise<br>P0452: Evaporative emission control system pressure sensor/switch low input<br>P0453: Evaporative emission control system pressure sensor/switch high input |
| Required Sensors / Components | Pump module                                                                                                                                                                                                                                                                                                     |
| Frequency of Operation        | Once pre driving cycle                                                                                                                                                                                                                                                                                          |
| Duration                      | 0.5 seconds: P0450, P0452, P0453<br>Within 15 seconds: P0451                                                                                                                                                                                                                                                    |
| MIL Operation                 | Immediate: P0450, P0452, P0453<br>2 driving cycles: P0451                                                                                                                                                                                                                                                       |
| Sequence of Operation         | None                                                                                                                                                                                                                                                                                                            |

## TYPICAL ENABLING CONDITIONS

### All:

|                                                          |      |
|----------------------------------------------------------|------|
| The monitor will run whenever these DTCs are not present | None |
|----------------------------------------------------------|------|

### Pressure sensor noise:

|                                                        |                                 |
|--------------------------------------------------------|---------------------------------|
| Atmospheric pressure                                   | 70 to 110 kPa (525 to 825 mmHg) |
| Battery voltage                                        | 10.5 V or more                  |
| IAT                                                    | 4.4 to 35°C (40 to 95°F)        |
| EVAP pressure sensor malfunction (P0450, P0452, P0453) | Not detected                    |
| Either of the following conditions is met              | Condition 1 or 2                |
| 1. Time after key off                                  | 5 or 7 or 9.5 hours             |
| 2. Engine condition                                    | Running                         |

### Pressure sensor stuck

|                                                        |                                 |
|--------------------------------------------------------|---------------------------------|
| Battery voltage                                        | 10.5 V or more                  |
| IAT                                                    | 4.4 to 35°C (40 to 95°F)        |
| EVAP pressure sensor malfunction (P0450, P0452, P0453) | Not detected                    |
| Atmospheric pressure                                   | 70 to 110 kPa (525 to 825 mmHg) |
| Time after key off                                     | 5 or 7 or 9.5 hours             |

### Pressure sensor chattering, low/high voltage

|                 |             |
|-----------------|-------------|
| Battery voltage | 8 V or more |
| Ignition switch | ON          |
| Starter         | OFF         |

## TYPICAL MALFUNCTION THRESHOLDS

### Pressure sensor noise:

|                                                                    |                                |
|--------------------------------------------------------------------|--------------------------------|
| Frequency that EVAP pressure change is 0.3 kPa (2.25 mmHg) or more | 10 times or more in 10 seconds |
|--------------------------------------------------------------------|--------------------------------|

### Pressure sensor stuck:

|                                                            |                             |
|------------------------------------------------------------|-----------------------------|
| EVAP pressure change during reference pressure measurement | Less than 1 kPa (0.75 mmHg) |
|------------------------------------------------------------|-----------------------------|

### Pressure sensor chattering:

|               |                                                                           |
|---------------|---------------------------------------------------------------------------|
| EVAP pressure | Less than 42.11 kPa (315.82mmHg), or more than 123.761 kPa (928.207 mmHg) |
|---------------|---------------------------------------------------------------------------|


### Pressure sensor low pressure:

|               |                                   |
|---------------|-----------------------------------|
| EVAP pressure | Less than 42.11 kPa (315.82 mmHg) |
|---------------|-----------------------------------|

### Pressure sensor high pressure:

|               |                                      |
|---------------|--------------------------------------|
| EVAP pressure | More than 123.761 kPa (928.207 mmHg) |
|---------------|--------------------------------------|

## WIRING DIAGRAM



ES

## INSPECTION PROCEDURE

### NOTICE:

- When a vehicle is brought into the workshop, leave it as it is. Do not change the vehicle condition. For example, do not tighten the fuel tank cap.
- Do not disassemble the pump module.
- The intelligent tester is required to conduct the following diagnostic troubleshooting procedure.

### 1 CONFIRM DTC AND EVAP PRESSURE

- Connect the intelligent tester to the DLC3.
- Turn the ignition switch on (do not start the engine).
- Turn the tester on.
- Select the following menu items: DIAGNOSIS / ENHANCED OBD II / DTC INFO / CURRENT CODES.
- Read DTCs.
- Select the following menu items: DIAGNOSIS / ENHANCED OBD II / DATA LIST / PRIMARY / VAPOR PRESS.
- Read the EVAP (Evaporative Emission) pressure displayed on the tester.

### Result

| Display (DTC Output) | Test Results                 | Suspected Trouble Areas                                                                                                                                 | Proceed to |
|----------------------|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| P0451                | -                            | Pressure sensor                                                                                                                                         | C          |
| P0452                | Less than 45 kpa (338 mmHg)  | <ul style="list-style-type: none"> <li>Wire harness/connector (ECM - pressure sensor)</li> <li>Pressure sensor</li> <li>Short in ECM circuit</li> </ul> | A          |
| P0453                | More than 120 kPa (900 mmHg) | <ul style="list-style-type: none"> <li>Wire harness/connector (ECM - pressure sensor)</li> <li>Pressure sensor</li> <li>Open in ECM circuit</li> </ul>  | B          |

B

Go to step 4


C

GO TO EVAP SYSTEM

A

### 2 CHECK HARNESS AND CONNECTOR (PUMP MODULE - ECM)

ECM:




- Turn the ignition switch off.
- Disconnect the E8 ECM connector.
- Measure the resistance between PPMP terminal of the ECM connector and the body ground.

**Result**

| Test Results        | Suspected Trouble Areas                                                                                                                    | Proceed to |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------|------------|
| 10 $\Omega$ or less | <ul style="list-style-type: none"> <li>Wire harness/connector (ECM - pressure sensor)</li> <li>Short in pressure sensor circuit</li> </ul> | A          |
| 10 $\Omega$ or more | <ul style="list-style-type: none"> <li>Wire harness/connector (ECM - pressure sensor)</li> <li>Short in ECM circuit</li> </ul>             | B          |

(d) Reconnect the ECM connector.

**B****Go to step 8****A****ES****3****CHECK HARNESS AND CONNECTOR (PUMP MODULE - ECM)**

- (a) Disconnect the L4 canister connector.  
 (b) Disconnect the E8 ECM connector.  
 (c) Measure the resistance between PPMP terminal of the ECM connector and the body ground.

**Result**

| Test Results          | Suspected Trouble Areas                                 | Proceed to |
|-----------------------|---------------------------------------------------------|------------|
| 10 k $\Omega$ or more | Short in pressure sensor circuit                        | A          |
| 10 k $\Omega$ or less | Short in wire harness/connector (ECM - pressure sensor) | B          |

(d) Reconnect the canister connector.

(e) Reconnect the ECM connector.

**B****Go to step 6****A****4****REPLACE CHARCOAL CANISTER ASSEMBLY**

- (a) Replace charcoal canister assembly (See page [EC-6](#)).  
 (b) Connect the intelligent tester to the DLC3.


- (c) Turn the ignition switch on and turn the tester on.
  - (d) Wait for at least 60 seconds.
  - (e) Select the following menu items on the tester:  
DIAGNOSIS / ENHANCED OBD II / DTC INFO /  
PENDING CODES.
- HINT:  
If no pending DTC is displayed on the tester, the repair  
has been successfully completed.

NEXT

COMPLETED

ES

5 CHECK HARNESS AND CONNECTOR (PUMP MODULE - ECM)



- (a) Disconnect the L4 canister connector.
  - (b) Turn the ignition switch on.
  - (c) Measure the voltage and resistance of the L4 canister connector.
- Standard**

| Tester Connections | Specified Conditions    |
|--------------------|-------------------------|
| L4-4 - Body ground | Between 4.5 V and 5.5 V |
| L4-3 - Body ground | Between 4.5 V and 5.5 V |
| L4-2 - Body ground | 100 Ω or less           |

Result

| Test Results                                      | Suspected Trouble Areas                                | Proceed to |
|---------------------------------------------------|--------------------------------------------------------|------------|
| Voltage and resistance is within standard ranges  | Open in pressure sensor circuit                        | A          |
| Voltage and resistance is outside standard ranges | Open in wire harness/connector (ECM - pressure sensor) | B          |

- (d) Reconnect the canister connector.

B Go to step 7

A

6 REPLACE CHARCOAL CANISTER ASSEMBLY

- (a) Replace charcoal canister assembly (See page EC-6).
- (b) Connect the intelligent tester to the DLC3.

- (c) Turn the ignition switch on and turn the tester on.
- (d) Wait for at least 60 seconds.
- (e) Select the following menu items on the tester:  
DIAGNOSIS / ENHANCED OBD II / DTC INFO /  
PENDING CODES.

HINT:

If no pending DTC is displayed on the tester, the repair has been successfully completed.

NEXT

COMPLETED

ES

7

#### REPAIR OR REPLACE WIRE HARNESS OR CONNECTORS

- (a) Repair or replace wire harness or connectors.
- (b) Connect the intelligent tester to the DLC3.
- (c) Turn the ignition switch on and turn the tester on.
- (d) Wait for at least 60 seconds.
- (e) Select the following menu items on the tester:  
DIAGNOSIS / ENHANCED OBD II / DTC INFO /  
PENDING CODES.

HINT:

If no pending DTC is displayed on the tester, the repair has been successfully completed.

NEXT

COMPLETED

8

#### REPLACE ECM

- (a) Replace the ECM (See page [ES-434](#)).
- (b) Connect the intelligent tester to the DLC3.
- (c) Turn the ignition switch on and turn the tester on.
- (d) Wait for at least 60 seconds.
- (e) Select the following menu items on the tester:  
DIAGNOSIS / ENHANCED OBD II / DTC INFO /  
PENDING CODES.

HINT:

If no pending DTC is displayed on the tester, the repair has been successfully completed.

NEXT

COMPLETED